



## DP-TUNER PCM CODE

---

---

The code is located on the PCM gray connector.



PCM Family

PCM Code

Before going any further,

**\*\*REMOVE KEY FROM IGNITION\*\***

Read and fully understand all instructions before attempting.



Using a mirror and flash light you can read the code located on the gray connector.

You can remove the PCM if the code can not be read with a mirror.

In the engine compartment, beneath the brake master cylinder, there is a wiring harness connected to the PCM. Make sure it is the single harness, closest to the fender well. Remove the 10mm bolt in the center of the harness, and pull away from the PCM.



Locate the PCM inside truck. The PCM will be behind the emergency brake pedal, close to the drivers' side, kick panel area. Remove the top and bottom 7mm bolts holding the black plastic PCM housing. Remove the PCM and the black plastic housing from the drivers' compartment. Note how the PCM fits into the housing for re-installation purposes. (In most cases there is an X on one side of the PCM, this X faces the fender.)